

# Samsung Phone Time change for Daylight Savings

Press **[TRSF] [2] [0] [0]**

Display will Show. 

ENABLE CUS. PROG PASSCODE:
-------------------------------

Press **[1] [2] [3] [4]**

Display will Show 

ENABLE CUS. PROG. DISABLE
------------------------------

Press **[1]**

Display will Show 

ENABLE CUS. PROG. ENABLE
-----------------------------

Press **[TRSF]** Display will return to normal

Press **[TRSF] [5] [0] [5]**

Display will Show 

OLD :XXXXXXXX:YYYY NEW:WMMDDYY:HHMM
----------------------------------------

XXXXXXXX:YYYY IS CURRENT DATE AND TIME)

Enter the new digits as follows:

- W = Day of week 0= Sunday 1= Monday etc
- MM = Month
- DD = Day
- YY = Year ( last 2 digits)
- HH = Hour in 24 hr format
- MM = Minute

NOTE for daylight savings you copy the OLD digits till you get to HH and adjust it up/down 1 hour, adjust minites if required or enter as per old.

You will hear 2 beeps to confirm entry after the minutes have been entered than

Press **[TRSF]**